

This addendum contains the following information:

- Installation Guide for the USB Dongle on the PC
- Installation of Software
- List of ghosted out features in GlobeCaster Animator/ Composer, GlobeCaster Effects Generator, and GlobeCaster Character Generator

Installing the USB Dongle



Figure 1.1: PC USB Dongle

1. While your PC is turned on, insert the USB dongle into an available USB port.




Figure 1.2: Example USB Port Location




Figure 1.3: PC with USB Dongle Installed

2. When the USB Dongle is first plugged into the USB port, Windows should recognize it and install the driver automatically. If Windows prompts you for the driver software just cancel out of the driver install program. When you run the Setup.exe on the Application cd the driver will be installed then.

3. Insert the **Application** cd into your cd-rom drive. Using *Explorer*, locate the file called **Setup.exe**. Launch this file by double-clicking on it. Setup.exe will install the necessary drivers and the applications.
4. You should now be able to work with Character Generator, Animator/Compositor, and Effects Generator.

NOTE: The USB dongle *must* remain attached to your PC in order for these applications to work.

If you need further assistance, contact the GlobalStreams Technical Support.

Notes About the Applications

The applications you are installing are the GlobeCaster **Animator/Compositor**, **Effects Generator**, and **Character Generator**. Some of the features in these applications will not be available to you because they utilize the full power of a GlobeCaster. The following is a list of the features that are unavailable to you. For more information on what these buttons do, please refer to their respective manuals.

**Animator/
Compositor**

In the Workspace Properties Panel, the following buttons are ghosted out.




Figure 1.4: Ghosted Out Buttons in the Workspace Properties Panel

**Effects
Generator**

On the main Effects panel, the following buttons are inactive:




Figure 1.5: Ghosted Out Buttons in Effects Generator

Character Generator

In the main panel (following figure), the **Auto** button is ghosted out




Figure 1.6: Auto Button in Titling Ghosted Out

On the **Page Properties Panel** (following figure), the **Auto Preview**, **Program Source**, **Preview Source**, and **Overlay Channel** are all ghosted out.



Figure 1.7: Ghosted Buttons on the Page Properties Panel